

Baja Customs

Install Instructions

BC-5079

Heater Hose Aluminum Fitting

Jeep Wrangler JL 2.0L i4 DOHC DI Turbo Engine

Scan here for the install video:



1. First remove the plastic engine cover. There are two 10mm screws in the top front, after those are removed pull up on the cover to release it from the rear clips.
2. Remove the hose clamps and large hose. Use a flathead screw driver to pull the locking wire clip into the unluck position on the old fitting. **Keep the clip it will be reused.**
3. With the fitting off remove the smaller hose. This is the barb end that usually breaks, so if yours is broken, make sure to remove the broken piece, if it remains in the tube when you pull it off.
4. Next remove the retaining wire clip off the old fitting and insert it into your new aluminum fitting. Push the clip all the way in.
5. Place the new fitting onto the male end of the coolant line. Push down until you hear the wire clip snap into place. Pull up on the fitting to make sure it is locked into place.
6. Lastly place the hoses and clamps onto the new fitting. You can reuse the stock clamps or use the new clamps provided with the kit if you are not confident in the stock clamps.

For technical assistance call: 949-229-0696 or email: info@bajacustoms.com